

# Abiie

## INSTRUCTION TO REMOVE SEAT PADDING



Abiie Seat Padding can be removed for cleaning.  
To remove it, the shoulder straps and waist belts need to be removed from the backbone of the backrest.

Due to child safety consideration, the straps are designed to secure firmly on the stroller to prevent them from coming off easily. However, it is relatively simple to remove it by following the steps below:



**Step 1**  
Reach underneath the fabric of the backrest and search for the buckles of the straps.



# Abiie

## INSTRUCTION TO REMOVE SEAT PADDING



Step 2.  
Carefully rotate the buckle so that the narrow end fits through the slot of the backbone.



Step 3.  
Push the buckle through to remove the strap.  
Repeat the above steps for the rest of the straps attached to backrest.

Remember to insert the buckles back when putting the seat padding back to the stroller.

Please contact us at anytime.  
Email: [myquestion@abiie.com](mailto:myquestion@abiie.com)